Ονοματεπώνυμο: Παναγιώτης Σταματόπουλος			Ομάδα: 6
<b>Όνομα PC/ΛΣ:</b> Takis Asus/Windows 10		Ημερομηνία: 5/10/23	
<b>Διεύθυνση ΙΡ:</b> 192.168.2.4	<b>Διεύθυνση Mac:</b> D4-5D-64-59-27-5F		

**AM:** el20096

## Εργαστηριακή Άσκηση 1 Αναλυτής Πρωτοκόλλων Wireshark

## Άσκηση 1:

\*Στον προσωπικό υπολογιστή

1.1: Realtek PCIe GbE Family Controller

Windows PowerShell > ipconfig/all

1.2: Ethernet

Windows PowerShell > ipconfig/all Wireless: Media Disconnected

1.3: 100 Mbps

Windows PowerShell > WMIC NIC

1.4: D4-5D-64-59-27-5F

Windows PowerShell > ipconfig/all

1.5: 192.168.2.4

Windows PowerShell > ipconfig/all

1.6: Δεν έχει ορισθεί

Windows PowerShell > ipconfig/all

1.7: 192.168.2.1

Windows PowerShell > ipconfig/all

1.8: 192.168.2.1

 $Windows\ PowerShell > ipconfig/all$ 

## Άσκηση 2:

\*Στον προσωπικό υπολογιστή

2.1: TakisAsus / Windows 10

Windows PowerShell > ipconfig/all

2.2: VirtualBox Host-Only Ethernet Adapter

TAP-Windows Adapter V9

Realtek 8821CE Wireless LAN 802.11ac PCI-E NIC

Microsoft Wi-Fi Direct Virtual Adapter #3

Microsoft Wi-Fi Direct Virtual Adapter #4

Realtek PCIe GbE Family Controller

Windows PowerShell > ipconfig/all

2.3: D4-5D-64-59-27-5F

*Windows PowerShell > ipconfig/all* 

2.4: 100 Mbps

Windows PowerShell > WIMC NIC

2.5: 192.168.2.4

*Windows PowerShell > ipconfig/all* 

2.6: 255.255.255.0

Windows PowerShell > ipconfig/all

- (i) 24 bits
- (ii) 192.168.2.0
- 2.7: fe80::a8a1:7b8f:2e87:345a%14 (link-local)

*Windows PowerShell > ipconfig/all* 

2.8: 192.168.2.1

*Windows PowerShell > ipconfig/all* 

2.9: 192.168.2.1

Windows PowerShell > ipconfig/all

2.10:192.168.2.1

Windows PowerShell > ipconfig/all

2.11: Unicast Packets Received: 29523162 / Sent: 34632702

Bytes Received: 3843837088 / Sent: 2254932944

 $Windows\ PowerShell > netstat-e\ -s$ 

2.12: Packets Received: 13051262 / Output Requests: 5832922

*Windows PowerShell >netstat -e -s* 

2.13: 38 Established TCP Connections

*Windows PowerShell >netstat -n* 

2.14: Source (49423)  $\rightarrow$  Destination (4070)

Source  $(50715) \rightarrow Destination (5228)$ 

*Windows PowerShell >netstat -n* 

## Άσκηση 3:

\*Στον υπολογιστή του εργαστηρίου

- 3.1: ARP, DB-LSP-DISC/JSON, DHCP, DNS, HTTP, ICMPv6, IGMPv3, NBSS, OSPF, SSDP, STP, TCP, TLSv1.2, TLSv1.3, VRRP
- 3.2: b0:22:7a:30:74:e0
- 3.3: HP
- 3.4: 147.102.38.115
- 3.5: 147.102.40.15
- 3.6: tcp.stream eq 5
- 3.7: i. Apache/2.2.22
  - ii. <title>CN Lab1</title>
  - iii. Στο label της καρτέλας του browser
- 3.8: ip.addr==147.102.40.15 and http
- 3.9: Sent 2 (147.102.38.115  $\rightarrow$  147.102.40.15) Received 2 (147.102.40.15  $\rightarrow$  147.102.38.115)
- 3.10: 0.001091 seconds
- 3.11: 7 packets  $\rightarrow$  No. 70 No. 76
- 3.12: ip.addr==147.102.40.15 and not http
- 3.13: i. HTTP  $\rightarrow$  TCP: 0.000746 seconds
  - ii. No.70 TCP  $\rightarrow$  No.76 TCP: 0 seconds
  - iii. HTTP Get → No.76 TCP: 0.000746 seconds
- 3.14: TRANSUM RTE Data:

Service Time: 0.000746 seconds

Response Spread: 0 seconds

APDU Response Time: 0.000746 seconds

3.15: ip.src == 147.102.38.115 and http